High level password – “one day licence”

To obtain a random code !
Write parameter 63 = 1

no change on the ramdom code
until enter a key code !

Read the ramdom code !
Read parameter 62

Ex: 3456

To obtain a key code !
Please, ➔ Contact Solvix

Solvix Encryption

Ex: 7460

Enter the key code !
Write parameter 63 = ...

max. 4 times
try to enter a code

Read the password level !
Read parameter 62

0 = no access
1 = low level access
2 = high level access

Enable to use
Supervisor commands
and parameters

To clear access level !
Write parameter 63 = 0

Read the password level !
Read parameter 62

0 = no access
1 = low level access
2 = high level access